



ZMS 20

Montageschlüssel für Einbaustecker
 SFV ... / SGV ... / SGR ...
 0314 ... / 0315 ... / 0316 ... / 0317 ...
 und Einbaukupplungen
 KfV ... / KGV ... / KFR ... / KGR ...
 0304 ... / 0305 ... / 0306 ... / 0307 ...

ZMS 20

Spanner for tightening mounting nuts for male sockets
 SFV ... / SGV ... / SGR ...
 0314 ... / 0315 ... / 0316 ... / 0317 ...
 and female sockets
 KfV ... / KGV ... / KFR ... / KGR ...
 0304 ... / 0305 ... / 0306 ... / 0307 ...

ZMS 20

Clé de montage pour embases châssis mâles
 SFV ... / SGV ... / SGR ...
 0314 ... / 0315 ... / 0316 ... / 0317 ...
 et embases châssis femelles
 KfV ... / KGV ... / KFR ... / KGR ...
 0304 ... / 0305 ... / 0306 ... / 0307 ...



0380

Montageschlüssel für Stecker 0331 ... / 0332 ...
 und Kupplungen 0321 ... / 0322 ...

0380

Spanner for plugs 0331 ... / 0332 ...
 and female plugs 0321 ... / 0322 ...

0380

Clé de montage pour fiches mâles 0331 ... / 0332 ...
 et fiches femelles 0321 ... / 0322 ...



0383

Schutzkappe für Stecker
 SV ... / WSV ... / 0331 ... / 0332 ...
 und Einbaustecker
 SFV ... / SGV ... / SGR ... / 0314 ... / 0315 ... / 0316 ... /
 0317 ...

0383

Dust cover for plugs
 SV ... / WSV ... / 0331 ... / 0332 ...
 and chassis plugs
 SFV ... / SGV ... / SGR ... / 0314 ... / 0315 ... / 0316 ... /
 0317 ...

0383

Bouchon de protection pour fiches mâles
 SV ... / WSV ... / 0331 ... / 0332 ...
 et pour embases châssis mâles
 SFV ... / SGV ... / SGR ... / 0314 ... / 0315 ... / 0316 ... /
 0317 ...



0381

Schutzkappe für Kupplungen
 KV ... / WKV ... / 0321 ... / 0322 ...
 und Einbaukupplungen
 KFV ... / KFR ... / KGV ... / KGR ... /
 0304 ... / 0305 ... / 0306 ... / 0307 ...

0381

Dust cover for female plugs
 KV ... / WKV ... / 0321 ... / 0322 ...
 and female chassis plugs
 KFV ... / KFR ... / KGV ... / KGR ... /
 0304 ... / 0305 ... / 0306 ... / 0307 ...

0381

Bouchon de protection pour fiches femelles
 KV ... / WKV ... / 0321 ... / 0322 ...
 et pour embases châssis femelles
 KFV ... / KFR ... / KGV ... / KGR ... /
 0304 ... / 0305 ... / 0306 ... / 0307 ...

0382

Schirmring für Einbaustecker 0314 .. / 0316 ..
 und Einbaukupplungen 0304 .. / 0306 ..

0382

Screening ring for chassis plugs 0314 .. / 0316 ..
 and female chassis plugs 0304 .. / 0306 ..

0382

Bague de blindage pour embases
 châssis mâles 0314 .. / 0316 ..
 et pour embases châssis femelles 0304 .. / 0306 ..

