

**ZMD31014** RBic<sub>iLite</sub><sup>TM</sup> Low-Cost Sensor Signal Conditioner with I<sup>2</sup>C and SPI Output SSC Evaluation Kit Documentation

Preliminary

## ZMD31014 RBic<sub>iLite</sub><sup>™</sup> Sensor Signal Conditioner SSC Modular Evaluation Kit Documentation

#### **Restrictions:**

The ZMD AG RBic<sub>Lite</sub><sup>™</sup> SSC Evaluation Kit hardware and software are designed for RBic<sub>Lite</sub><sup>™</sup> evaluation, laboratory setup and module development only.

The ZMD AG RBic<sub>Lite</sub> <sup>TM</sup> SSC Evaluation Kit hardware and software must not be used for module production and production test setups. ZMD AG shall not be liable for any damages arising out of defects resulting from (i) delivered hard and software (ii) non-observance of instructions contained in this manual, or (iii) misuse, abuse, use under abnormal conditions or alteration by anyone other than ZMD AG. To the extent permitted by law, ZMD AG hereby expressly disclaims and User expressly waives any and all warranties, whether express, implied or statutory, including, without limitation, implied warranties of merchantability and of fitness for a particular purpose, statutory warranty of non-infringement and any other warranty that may arise by reason of usage of trade, custom or course of dealing.

Preliminary ZMD31014 SSC Evaluation Kit, Rev. 0.2, April 18, 2008

Page 1 of 39



## RBic<sub>iLite<sup>™</sup></sub> Low-Cost Sensor Signal Conditioner with I<sup>2</sup>C and SPI Output

SSC Evaluation Kit Documentation

Preliminary

### Contents

1	κιτ	CONTENTS	4
2	USE	3 DRIVER INSTALLATION	5
	2.1	SYSTEM REQUIREMENTS	5
	2.2	INSTALLATION FOR WINDOWS® XP PRO OR XP HOME OPERATING SYSTEMS	5
		Installing the Basic USB Driver	5
		Installing the Virtual Com Port USB Driver	6
		Checking USB Port Operation	7
3	ZMI	D31014 SSC EVALUATION BOARD	8
	3.1	OVERVIEW	8
	3.2	INSTALLING THE COMMUNICATION AND CALIBRATION SOFTWARE	9
	3.3	CONNECTIONS TO RBICILITE <sup>TM</sup>	9
	3.4	POWER SUPPLY TO THE BOARD	9
	3.5	RESET SWITCH	9
4	RBI	C <sub>ILITE</sub> ™ TESTER SOFTWARE	10
	4.1	OVERVIEW	10
	4.2	"FIND COM" BUTTON	10
	4.3	"I2C COMM ADDR" FIELD	11
	4.4	BRIDGE AND TEMPERATURE DISPLAY	11
	4.5	"LOG FILE" FIELD	11
	4.6	"START CM" BUTTON	11
	4.7	"START NOM" BUTTON	11
	4.8	"NORMAL MODE" SECTION	12
		"Run Continuous" Button	12
		"Sample Rate" Field	12
		"Average Samples" Field	12
	4.9	"EEPROM EDITOR" SECTION	12
		"Read" Button	12
		"Load File" Button	12
		"Save File" Button	13
	4.1	0 "COMMUNICATION AND OPERATION CONFIG" SECTION	13
		"Comm Type" Menu	13
		"Clock Freq" Menu	13
		"I2C Addr" Field	13
		"Lock I2C Address" Checkbox	13
			_

Preliminary ZMD31014 SSC Evaluation Kit, Rev. 0.2, April 18, 2008

Page 2 of 39

© ZMD AG, 2008



## $RBic_{iLite}$ <sup>TM</sup> Low-Cost Sensor Signal Conditioner with I<sup>2</sup>C and SPI Output

SSC Evaluation	Kit Documentation	1
----------------	-------------------	---

#### Preliminary

	"	"Sleep Mode" Checkbox	13
	"	"Update_Rate" Menu	13
	"	"Sensor Short Check" Checkbox	13
	"	"Sensor Connection Check" Checkbox	13
	4.11	MATH CONFIG SECTION	14
	"	"SOT_Curve" Menu	14
	ŕ	"Negative Coeffs" Subsection	14
	4.12	"FRONT END CONFIG" SECTION	14
	"	"A2D_Offset" Menu	14
	"	"PreAmp_Gain" Menu	15
	"	"Negative" Checkbox	15
	"	"LongInt" Checkbox	15
	"	"BSink" Checkbox	15
	"	"Gain8X" Checkbox	15
	4.13	"CALIBRATION" BUTTON	16
	"	"Get ID" Button	16
5	CALI	IBRATION	17
	5.1	CALIBRATION SEQUENCE	17
	3	Step 1 – Assigning a Unique Identification (ASIC ID Section)	
	3	Step 2 – Data Collection	
	5	Step 3 – Calculating and Writing the Coefficients	19
	5.2	DRY RUN CALIBRATION	20
	3	Steps for a Dry Run Calibration using the Artificial Bridge on the Evaluation Board:	20
	3	Steps for a Dry Run Calibration using the Sensor Replacement Board:	21
6	ZMD	31014 SOFTWARE WITH THE ZMD SSC TERMINAL	23
	6.1	PROTOCOL	23
	6.2	ZMD SSC TERMINAL	23
7	СОМ	IMAND/DATA PAIR ENCODING	
8	EEPF	ROM BITS	
9	REL	ATED DOCUMENTS	
AP	PEND	IX A: SCHEMATIC RBICILITE <sup>TM</sup> SSC EVALUATION BOARD	
AP	PEND	IX B: LIST OF ERROR MESSAGES IN THE SOFTWARE	
AP	PEND	IX C: FORMAT OF THE CALDATA.TXT FILE	
AP	PEND	IX D: DRIVER INSTALLATION ON WINDOWS 2000 OPERATING SYSTEMS	



SSC Evaluation Kit Documentation

Preliminary

#### 1 Kit Contents

- a) SSC CD ROM including RBic<sub>iLite</sub><sup>TM</sup> Tester/Calibration Software
- b) SSC Communication Board (SSC CB), including USB Cable
- c) SSC ZMD31014 Evaluation Board
- d) SSC Sensor Replacement Board (SRB)



Figure 1.1 – ZMD31014 SSC Evaluation Kit

The RBic<sub>iLite</sub><sup>TM</sup> SSC Evaluation Kit contains the software and hardware needed for communication and calibration of an RBic<sub>iLite</sub><sup>TM</sup> sensor signal conditioning IC. A PC can communicate with an RBic<sub>iLite</sub><sup>TM</sup> socketed on the SSC Evaluation Board via an SSC Communication Board through a USB connection. The software should function on any Windows® 98/ME/XP/NT system after installation of a USB driver. Both the SSC Evaluation Board and the Sensor Replacement Board (SRB) can provide a replacement for a sensor. Only one of these can be used at a time for calibration as determined by the settings of jumpers K6 and K7 (see Figure 3.1). On the SRB, the sensor replacement is controlled by a potentiometer (see Figure 1.1). The SRB can be disconnected if the SSC Evaluation Board's sensor replacement (artificial bridge stimulus) will be used.



### RBic<sub>iLite</sub><sup>™</sup> Low-Cost Sensor Signal Conditioner with I<sup>2</sup>C and SPI Output

SSC Evaluation Kit Documentation

Preliminary

#### 2 USB Driver Installation

#### 2.1 System Requirements

- 5x86-compatible PC
- 32 MB RAM
- Hard drive with 20MB free space
- USB port
- Microsoft® W98/ME/2000/XP

The USB version of the ZMD31014 RBic<sub>iLite</sub><sup>TM</sup> SSC Evaluation Kit requires installation of two drivers. All the required driver files are in the "USB\_Driver" folder on the SSC Evaluation Kit CD-ROM.

These two drivers make the PC's USB port appear as a virtual COM port (typically COM3 or COM4 on most computers). The software provided with the SSC Evaluation Kit accesses the SSC Evaluation Board as if it were a COM (RS232) port. These drivers will not affect the operation of any other USB peripherals.

Driver installation is very similar for Windows® XP or Windows 2000 installations; however, there are slight differences in the appearance of the dialog boxes. Windows® XP installation procedures are given below. Similar steps for Windows® 2000 installation are given in Appendix A in this document.

#### 2.2 Installation for Windows® XP Pro or XP Home Operating Systems

#### Installing the Basic USB Driver

Important: System administrator rights are required to install the USB driver on your PC.

Use the USB cable to connect the SSC Evaluation Board to an available USB port on your PC. The "Found New Hardware" wizard launches and brings up the following dialog box. Complete the following steps.



Step 1: Select "No, not this time," and click "Next."



Step 2: Select "Install from a list or specific location (Advanced)." Click "Next."

Preliminary ZMD31014 SSC Evaluation Kit, Rev. 0.2, April 18, 2008



## $RBic_{iLite}$ <sup>TM</sup> Low-Cost Sensor Signal Conditioner with I<sup>2</sup>C and SPI Output

#### SSC Evaluation Kit Documentation

Preliminary

Please cho	ose your search and installation options.
💽 Searc	h for the best driver in these locations.
Use th paths	re check boxes below to limit or expand the default search, which includes local and removable media. The best driver found will be installed.
<b>V</b>	Search removable media (floppy, CD-ROM)
	Include this location in the search:
	Browse
🔘 Don't	search. I will choose the driver to install.
Choos the dri	e this option to select the device driver from a list. Windows does not guarantee that ver you choose will be the best match for your hardware.
	< Back Next > Cancel

Step 3: Select "Search removable media (floppy, CD-ROM)," and click "Next."

Har dwa	re Installation
⚠	The software you are installing for this hardware: USB High Speed Serial Converter has not passed Windows Logo testing to verify its compatibility with Windows XP. (Tell me why this testing is important.) Continuing your installation of this software may impair or destabilize the correct operation of your system either immediately or in the future. Microsoft strongly recommends that you stop this installation now and contact the hardware vendor for software that has passed Windows Logo testing.
	Continue Anyway STOP Installation

Step 4: When the warning about failing logo testing appears, click "Continue Anyway" because this concern is not applicable.



Step 5: Finish the driver installation by clicking "Finish."

#### Installing the Virtual Com Port USB Driver

The second required USB driver causes the USB device to appear to the system as a virtual COM port.

Follow the same steps as outlined under *Installing the Basic USB Driver* above to complete this second driver installation.

Page 6 of 39



## **RBic**<sub>iLite</sub><sup>™</sup> Low-Cost Sensor Signal Conditioner with I<sup>2</sup>C and SPI Output

#### SSC Evaluation Kit Documentation

Preliminary

System Restore	Automatic Updates	Remote	before continuing Access
General Com	uter Name Hardware	Advanced	before continuing. Access
			Start → Settings → Conti
Add Hardware Wizard-			"System" icon. The adjace
The Add Han	ware Wizard helps you install hardv	ware.	Click on the "Hardware" t
×			Manager " This brings up
			Manager. This bings up
	Add Hardwar	re Wizard	If the USB is operating pr
Denting Managem			tion Kit (COMx)" appears
Device Manager	An an an a linter all also he and some also day		Typically, the "x" is 3 or 4
on your comp	uter. Use the Device Manager to cl	hange the	port number. It is the CO
properties of	any device.	-	the software provided with
Driver	Signing Device Mr		
Dilver	Signing Device Ma	snager	
Hardware Profiles			
Hardware pm	files provide a way for you to set up	and store	
different hard	ware configurations.		
	Hardware	Profiles	
	OK Cancel	Apply	
			• /
🚨 Device Mana	ger		
<u>File A</u> ction <u>V</u> i	ew <u>H</u> elp		
← → I m I 4	3 🕑 🕅		
	¥   ⊡s   ⊡s		
	PTOP		
🕀 📲 Batteria	s		
🖃 😗 Comput	er		
🕂 🥪 Disk dri	/es		
H Display	adapters		
	-ROM arives		
	A/ATAPI controllers		
H M Infrare	i devices ide		/
H Mice an	d other pointing devices	/	/
Handem	s oanar pointang devices		
	5		
⊕      ⊞     ■     Networ	- Kadapters		
	adapters		
🖻 🖉 Ports ((	OM & LPT)		
Cor	munications Port (COM1)	/	
🥏 Prin	ter Port (LPT1)	/	
· · · · · · · · · · · · · · · · · · ·	SEC EURIDERIAE KIR (COME)	•	

#### on

is operating properly control panel by clicking anel. Double click the lialog box appears.

and then on "Device dialog box shown below.

ly, "ZMD SSC Evaluaer "Ports (COM & LPT)." member this virtual COM rt to select when using SSC Evaluation Kit.

Preliminary ZMD31014 SSC Evaluation Kit, Rev. 0.2, April 18, 2008

Sound, video and game controllers

+ Processors

÷

Page 7 of 39



## **ZMD31014** RBic<sub>iLite<sup>TM</sup></sub> Low-Cost Sensor Signal Conditioner with I<sup>2</sup>C and SPI Output SSC Evaluation Kit Documentation

Preliminary

#### 3 ZMD31014 SSC Evaluation Board

#### 3.1 Overview



Figure 3.1 – SSC Evaluation Board Overview

The main purpose of the SSC Evaluation System is communication between the PC and the  $Bic_{iLite}^{TM}$  IC. The PC sends commands and data via the USB / SSC CB (virtual COM port). The  $\mu$ Controller on the SSC CB interprets these commands and relays them to the  $Bic_{iLite}^{TM}$  in the I<sup>2</sup>C bus standard format (K1 Pin 9/SCL Pin 11/SCK). The  $\mu$ Controller will also forward any data bytes from the  $Bic_{iLite}^{TM}$  chip back to the PC via the USB connection. These bytes can be bridge and temperature readings to be displayed by the PC software; raw ADC readings used during calibration; or EEPROM content bytes.



### **RBic**<sub>iLite</sub><sup>™</sup> Low-Cost Sensor Signal Conditioner with I<sup>2</sup>C and SPI Output

#### SSC Evaluation Kit Documentation

Preliminary

#### 3.2 Installing the Communication and Calibration Software

To install the RBic<sub>iLite</sub><sup>TM</sup> SSC Evaluation Kit CD-ROM on the PC hard drive, locate the *setup.exe* file in the root directory of the CD-ROM, and double click on it. The software completes the installation.

#### 3.3 Connections to RBic<sub>iLite</sub><sup>™</sup>

The SSC Evaluation Board has an SOP-8 socket for inserting the RBic<sub>iLite</sub><sup>TM</sup>.

Using the VDD, GND, SDA/MISO, SCL/SCLK and INT/SS/ connections on connector K5 on the SSC Evaluation Board, the board can be used for in-circuit programming of the RBic<sub>iLite</sub><sup>TM</sup> IC in the user's calibration fixture.

**NOTE:** Only one ASIC connection option can be used at a time.

#### 3.4 Power Supply to the Board

The K1 connector to the SSC CB provides the power supply from the SSC CB's USB port to the SSC Evaluation Board. Using the power via the USB port, the maximum current that can be provided is 40mA. All functions of the board are operative down to 2.7V. The board has a red LED labeled D1, which lights if the board has power.

#### 3.5 Reset Switch

Use the push button on the Communication Board to reset communications if needed.



SSC Evaluation Kit Documentation

Preliminary

#### 4 RBic<sub>iLite</sub><sup>™</sup> Tester Software

#### 4.1 Overview

The ZMD software provided with this SSC Evaluation Kit is intended for demonstration purposes and calibration of single units. ZMD can provide the user with algorithms and assistance in developing their full production calibration software. Five types of text files support the software user:

- When the software is activated, a CommLog.txt file is saved to the application folder (C:\\program files\ZMD America\ZMD31014\_iLite). This file is a log of the communication to the IC during the software session and can be saved after closing the software by renaming the file. Otherwise, it would be overwritten the next time the software will be opened.
- In Command Mode (CM) the user can save/load the EEPROM contents from a text file to the EEPROM and vise versa.
- In Normal Operation Mode (NOM) the user can log bridge and temperature readings to the *DataLog.txt* file.
- The caldata.txt file is used by the software for calibration. Its structure is explained in Appendix C.
- The calibration is documented in the *CalibrationLog.txt* file, which is more convenient for users than the *caldata.txt* file.

#### 4.2 "Find Com" Button

The RBic<sub>iLite</sub><sup>™</sup> Tester software automatically detects which type of ZMD evaluation board is connected. To set up communication with the SSC CB, click on "Setup" and then "Find COM." Click "Yes" in the resulting dialog box if the COM port selected is acceptable. If not, click "No" until an acceptable COM port is found.



**Figure 4.1** – Setting Up Communications

Preliminary ZMD31014 SSC Evaluation Kit, Rev. 0.2, April 18, 2008

Page 10 of 39



SSC Evaluation Kit Documentation

Preliminary

#### 4.3 "I2C Comm Addr" Field

Use the "I2C Comm Addr" field to enter the address that the SSC CB uses to communicate with the RBic<sub>iLite</sub><sup>™</sup> installed in the socket on the Evaluation Board. Valid settings are 0x00 to 0x7FH. The default is 0x28H. See important notes in section 4.10 regarding settings when the communication address is locked.

#### 4.4 Bridge and Temperature Display

The software displays two large readout windows for temperature and bridge values. The temperature reading is the RBic<sub>iLite</sub><sup>TM</sup> temperature in °C. The bridge reading is in %. Calibration determines the relationship of the % reading to the value the bridge is measuring.

The RBic<sub>iLite</sub><sup>TM</sup> is designed to be a generic resistive bridge conditioner, but for the following calibration example, assume it is connected to a pressure bridge. If the unit is calibrated to read pressure with 50kPa reading as 100% and 10kPa reading as 0%, then the span of pressure readings would be 40kPa. Half of that span (20kPa) plus the set zero point (10kPa) should be the 50% point. After calibration, if the chamber is set to 30kPa, the RBic<sub>iLite</sub><sup>TM</sup> should give a 50% reading.

There is a continuous transmission of bridge readings and temperature readings.

If the RBic<sub>iLite</sub><sup>TM</sup> has not been temperature calibrated, the displayed temperature is invalid.

The different colors of the display field indicate the IC mode:

Color	Green	Blue	Red	Yellow
IC Mode/State	Valid value (NOM)	Valid (CM)	Diagnostic	Invalid value (NOM) <sup>1</sup>

#### 4.5 "Log File" Field

Bridge and temperature readings can be logged to a PC file. Use the "Browse" button to select the filename and directory where the file will be stored. Then click "Open." The "Sample Rate" field sets how often the data is collected. If the sample rate is 0 sec, then an entry is written for each transmission from the RBic<sub>iLite</sub><sup>TM</sup>.

The resulting text file is a space-delimited ASCII file and can be imported into Microsoft Excel®.

#### 4.6 "Start CM" Button

To communicate to the RBic<sub>iLite</sub><sup>TM</sup>, start the Command Mode (full command set, measurement cycle stopped) by clicking "START CM" (Start Command Mode).

#### 4.7 "Start NOM" Button

To exit Command Mode and return the RBic<sub>iLite</sub><sup>TM</sup> to Normal Operation Mode (reading, conditioning and transmitting bridge data), click "START NOM" (Start Normal Operation Mode).

Note: For the ZMD31014, the NOM is recommended for the raw value collection during the calibration.

<sup>&</sup>lt;sup>1</sup> For more details refer to section 3 of the *ZMD31014\_iLite\_Datasheet.pdf*.



SSC Evaluation Kit Documentation

Preliminary

#### 4.8 "Normal Mode" Section

#### "Run Continuous" Button

To start a continuous readout of bridge and temperature data, click the "Run Continuous" button.

#### "Sample Rate" Field

This field sets the period (ms) for the sample rate of the continuous read out. Valid settings are 10ms or longer.

#### "Average Samples" Field

This feature allows averaging the measured values by choosing the number of samples to average before displaying the result.

#### 4.9 "EEPROM Editor" Section

Read Load File Save File					
Addr	Data	Description			
0x00	0x0002	Customer ID 0			
0x01	0x0018	Config 0			
0x02	0x0000	Config 1			
0x03	0xFE40	Offset B			
0x04	0xF5F9	Gain B			
0x05	0x0000	Tog			
0x06	0x0000	Tco			
0x07	0x0000	SOT Tco			
0x08	0x0000	SOT Tog			
0x09	0x0000	SOT B			
0x0A	0x0000	Offset T			
0x0B	0x2000	Gain T			
0x0C	0x0000	SOT T			
0x0D	0x296F	Tsetl			
0x0E	0x2000	Zero Point			
0x0F	0x0AF8	B Config			
0x10	0x0018	T Config			
0x11	0x0000	Reserved			
0x12	0x4DAD	Signature			
0x13	0x0000	Customer ID 1			

Figure 4.2 – EEPROM Editor

#### "Read" Button

To read EEPROM settings, enter the Command Mode and click the "Read" button. The "EEPROM" section displays all of the fields currently stored in the RBic<sub>iLite</sub><sup>TM</sup> EEPROM (non-volatile memory). Double clicking on the contents allows editing the EEPROM content. The EEPROM signature will be changed after the Command Mode is exited (Start\_NOM).

#### "Load File" Button

EEPROM contents that have been previously saved in a text file can be written to the current EEPROM by clicking the "Load File" button. The default folder for the saved text file is *C:\program files\ZMD America\ZMD31014\_iLite*. The standard Windows™ dialog box for file saving results.

Preliminary ZMD31014 SSC Evaluation Kit, Rev. 0.2, April 18, 2008

Page 12 of 39



#### SSC Evaluation Kit Documentation

Preliminary

#### "Save File" Button

The EEPROM contents can be saved in a text file in the *C*:\*program files*\*ZMD America*\*ZMD31014\_iLite* directory by clicking the "Save File" button. The standard Windows<sup>™</sup> dialog box for file saving results.

#### 4.10 "Communication and Operation Config" Section

This section is used to expedite programming configuration and communication settings in the EEPROM of the ZMD31014 RBic<sub>iLite</sub>™ under test.

#### "Comm Type" Menu

Three communication options are available on the "Comm Type" drop-down menu:

- I2C
- SPI (pos edge): SPI / MISO changes on positive edge clock frequency
- SPI (neg edge): SPI / MISO changes on negative edge clock frequency

#### "Clock Freq" Menu

Select 1MHz or 4MHz for the clock frequency for the ZMD31014 RBic<sub>iLite</sub> using the "Clock Freq" drop-down menu. The lower clock frequency (1MHz) is the recommend selection for lower power and better noise performance. If faster response time is required, the 4MHz clock frequency setting is needed.

#### "I2C Addr" Field

When the ZMD31014 RBic<sub>iLite</sub> is in I<sup>2</sup>C communication mode, the default slave address is 0x28H. If a different slave address is required, program the part for the new address by entering the hex value of the new address in the "I2C Addr" field and then click "Write Addr." The valid address range is 0x00 to 0x7FH.

Note: If the "Lock I2C Address" is on (see below), "I2C Addr" must match the "I2C Comm Addr" setting (see section 4.3).

#### "Lock I2C Address" Checkbox

Lock the slave address selection by clicking "Lock I2C Address" checkbox. Without this lock, the IC will respond to all I2C addresses.

#### "Sleep Mode" Checkbox

To select the Sleep Mode, click on the "Sleep Mode" checkbox; otherwise, the Update Rate Mode is selected as the default mode. The Sleep Mode enables the most power saving mode of the ZMD31014 RBic<sub>iLite</sub>.

#### "Update\_Rate" Menu

When operating in Update Mode, the update rate determines power consumption and response time. Select the update rate by clicking on one of the four update rates on the "Update\_Rate" drop-down menu.

#### "Sensor Short Check" Checkbox

To enable the sensor short diagnostic, click on the "Sensor Short Check" checkbox.

#### "Sensor Connection Check" Checkbox

To enable the sensor open diagnostic, click on the "Sensor Connection Check" checkbox.



SSC Evaluation Kit Documentation

Preliminary

#### 4.11 Math Config Section

#### "SOT\_Curve" Menu<sup>1</sup>

Some sensors perform better when compensated with a second order term (SOT) based on a zero-point symmetrical output function (S-shaped) instead of the parabolic curve function used to compensate more common sensors. The curve type is controlled by SOT\_Curve (bit 9 in EEPROM word 0x01). Select the curve type from the "SOT\_Curve" drop-down menu. When the S-shaped curve is selected, the zero point is in the middle of the output and a negative and positive output signal can be compensated using only the 2<sup>nd</sup> order term.

#### "Negative Coeffs" Subsection

The Tco, Tcg, SOT\_Bridge, SOT\_Tco, SOT\_Tcg and SOT\_T checkboxes in the "Negative Coeffs" section indicate the sign of the calculated calibration coefficients after calibration.

#### 4.12 "Front End Config" Section

In the "Front End Config" section, select the configuration for the AFE (Analog Front End) as determined from the bridge sensor performance before starting calibration. The configuration for the temperature depends on the choice of an internal or external temperature sensor. For the internal sensor, a default calibration word is configured. Additional selections are available in the "Calibration/Set ASIC Configuration" window (click "Calibration" to initialize).

Note: The Excel<sup>™</sup> file *ZMD31014* AFE Configuration.xls can be used to determine the correct adjustment of the analog PreAmp gain and the analog A2D offset modes based on the known sensor characteristics. The Excel<sup>™</sup>sheet *ZMD31014\_iLite\_ext\_Temperaturemeasurement.xls* can be used to determine the configuration for external temperature sensors.

#### "A2D\_Offset" Menu

To help compensate for bridges that have a large inherent offset, the ZMD31014 RBic<sub>iLite</sub> has seven programmable analog offset modes for bridge and temperature measurements:

[-15/16,1/16] [-7/8,1/8] [-3/4,1/4] [-1/2,1/2] [-1/4,3/4] [-1/8,7/8] [-1/16,15/16]

Use the "A2D\_Offset" drop-down menus for "Bridge" and "Temperature" to select the A2D offset mode settings, which are stored in EEPROM.

The [-1/2, 1/2] mode is best for a balanced bridge [-50mV, 50mV] @ VDD=5V (Pre-Amp=24).The [-1/16, 15/16] mode is best for positive-skewed bridges [-10mV, 90mV] @VDD=5V (Pre-Amp=24).

Note for External Temperature Sensors: The A2D\_Offset is always [-1/16, 15/16] for external temperature sensors.

<sup>&</sup>lt;sup>1</sup> For the ZMD31014 RBic<sub>iLite</sub> revision A, only the parabolic curve is usable.



#### SSC Evaluation Kit Documentation

Preliminary

Note: As a single ended input, the temperature input signal must fit in the voltage range 1V to (VDD/2-1.2V).

#### "PreAmp\_Gain" Menu

The ZMD31014 RBic<sub>iLite</sub> PreAmp amplifies the bridge signal to produce the differential signal that will be converted by the ADC. The PreAmp has eight possible analog gain settings: 1.5, 3, 6, 12, 24 (default), 48, 96, and 192<sup>1</sup>. Use the "PreAmp\_Gain" drop-down menus for "Bridge" and "Temperature" to select the PreAmp gain settings, which are stored in EEPROM. (Note: This term is different from the digital gain terms Gain\_B and Gain\_T, which are multiplied by the result of the ADC to compensate sensor span for bridge and temperature measurements.)

Any bridge input signal greater than 40mV/V in differential mode will saturate the pre-amp if the gain is set to 24 (default). In this case, the pre-amp gain must be set to the lower value 12.

For very small differential input signals, the higher analog gain (e.g., 40) can improve the output resolution (see section 1.4 in the datasheet), but the sensor offset must always be considered as well as sensor span. Both the offset and span of the sensor are amplified by the pre-amp. With a high analog gain (48), the total offset plus span cannot exceed 20mV/V differential. Otherwise the input to the ADC will be saturated.

Note for External Temperature Sensors: The PreAmp\_Gain is usually set to 3 or 5, which always guarantees the specified resolution.

Note: As a single ended input, the temperature input signal must fit in the voltage range 1V to (VDD/2-1.2V).

#### "Negative" Checkbox

To select negative bridge gain polarity, click on the "Negative" checkbox.

#### "LongInt" Checkbox

To select the longer conversion time for low noise, click on the "LongInt" checkbox. (For more details see the *ZMD31014 RBic<sub>iLite</sub><sup>TM</sup>Datasheet.*)

#### "BSink" Checkbox

To enable the BSink power-saving option, click on the "BSink" checkbox.

#### "Gain8X" Checkbox

To multiply the Gain\_B value (EEPROM word 0x04) by a factor of 8, click on the "Gain8X" checkbox.

<sup>&</sup>lt;sup>1</sup> For the previous silicon revision (A), the PreAmp gain settings were 1, 3, 5, 15, 24 (default), 40, 72, and 120.



### $RBic_{iLite}$ <sup>TM</sup> Low-Cost Sensor Signal Conditioner with I<sup>2</sup>C and SPI Output

SSC Evaluation Kit Documentation

Preliminary

#### 4.13 "Calibration" Button

To initiate a calibration run, click the "Calibration" button. This results in the calibration screen and dialog box shown below. See section 5 for a full description of calibration and settings used on the "Calibration" window.

	nitialization			Status:		
Start # 1		lr	nitialize			<u> </u>
Num Asics 1 Power	On Delay 0.0	_s(	Get ID			~
Artific	ial Stimulus:			Common Ca	alibration	Types
			0x800	2pt - Gain_B, Offset	Ь	~
Î	•	Min Cal Points	: 2	2pt - Gain B, Offset 3pt - Gain B, Offset 4pt - Gain B, Offset 6pt - Gain B, Offset 7pt - All	b _B, SOT _B, Tc's _B, Tc's,	_B SOT_Tc's
				SOT_B 📃		0x0
				Tco 📃		0x0
e				SOT_Tco 📃		0x0
Brid				Tog 📃		0x0
-				SOT_Tcg 📃		0x0
				Offset_T 📃		0x0
				Gain_T 📃		0x2000
	•			SOT_T 🗖		0x0
				Rese	t Default:	s
Ten	nperature	Calibration Poir		Calculate & \	Write Coe	fficients
Bridge (%): Temper	ature (°C):	Add Poi	nt Rer	move Point S	ave	Load

Figure 4.3 – Calibration Window

#### "Get ID" Button

The "Get ID" feature is not available yet for the RBic<sub>iLite</sub>™.



SSC Evaluation Kit Documentation

Preliminary

#### 5 Calibration

#### 5.1 Calibration Sequence

Although the RBic<sub>iLite</sub><sup>TM</sup> can function with many different types of resistive bridges, assume it is connected to a pressure bridge for the following calibration example. In this case, calibration essentially involves collecting raw bridge and temperature data from the RBic<sub>iLite</sub><sup>TM</sup> for different known pressures and temperatures. This raw data can then be processed by the calibration master (the PC), and the calculated coefficients can then be written to the EEPROM of the RBic<sub>iLite</sub><sup>TM</sup>.

The software ZMD provides with the SSC Evaluation Kit is intended for demonstration purposes and calibration of single units. ZMD can provide customers with algorithms and assistance in developing their full production calibration software. For the following steps, refer to the calibration window shown in Figure 4.3.

#### There are three main steps to calibration:

- 1. Assigning a unique identification to the RBic<sub>iLite</sub><sup>TM</sup>. This identification is programmed in EEPROM Cust\_ID0 and Cust\_ID1 registers and can be used as an index in the database stored on the calibration PC. This database will contain all the raw values of bridge readings and temperature readings for that part, as well as the known pressure and temperature to which the bridge was exposed.
- 2. Collecting data. Data collection involves getting raw data from the bridge at different known pressures and temperatures. This data is then stored on the calibration PC using the unique identification of the RBic<sub>iLite</sub><sup>TM</sup> as the index into the database.
- 3. Calculating and writing coefficients to EEPROM. After enough data points have been collected to calculate all the desired coefficients, the coefficients can be calculated by the calibrating PC and written to the EEPROM of the RBic<sub>iLite</sub><sup>TM</sup>.

Initialization       Start # 1       Num Asics 1       Power On Delay       0.0       s							
	Dialog						
Bridge	Sleep_Mode Cancel OK Clk_Freq: 4 MHz Comm_Type: 12C V Update_Rate: 5ms/1.28r SOT_Curve: Parabolic V Front End Configuration Bridge Temp PreAmp_Mux: Bridge Internal V A2D_Offset: [·1/2.1/2] (1/2,1/2] V PreAmp_Gain: 24 6 V Positive Gain: Cancel OK						

Figure 5.1 – Initialization Configuration Dialog Box

Preliminary ZMD31014 SSC Evaluation Kit, Rev. 0.2, April 18, 2008

Page 17 of 39



#### SSC Evaluation Kit Documentation

Preliminary

#### Step 1 – Assigning a Unique Identification (ASIC ID Section)

In the top middle of the calibration screen (see Figure 4.3), click on "Initialize." In the resulting dialog box (see Figure 5.1), verify or correct the configuration for the ZMD31014 RBic<sub>iLite</sub> under test and then click OK to initialize the part. The part is assigned a unique ID, which is used as an index in the database. This unique ID is also programmed into the EEPROM Cust\_ID0 and Cust\_ID1 registers. The software automatically loads and writes unity values for Gain\_B and Gain\_T to the EEPROM and set the Offset\_B to an ADC\_Offset related value. All other coefficients are set to zero. The raw data are collected with these settings in NOM.

Note: The default values shown in this dialog window are the previous settings and can differ from the actual EEPROM contents, which will be overwritten by clicking the OK button.

#### Step 2 – Data Collection

#### "Common Calibration Type" Menu

Next, select the type of calibration required from the "Common Calibration Type" pull-down menu in the top right of the calibration screen (see Figure 4.3). The number of unique points (for this example, pressure and temperature points) at which calibration must be performed depends on the user's requirements. The minimum is a 2-point calibration, and the maximum is a 7-point calibration.

Depending on the number of calibration temperature points, a linear or second order temperature correction is performed with 2 or 3 (respectively) temperature coefficients (Offset\_T&Gain\_T or Offset\_T&Gain\_T&SOT\_T).

In the left section of the calibration screen (see Figure 4.3), there is a graph (X-axis = Temperature, Y-axis = Bridge). This graph outlines the recommended spread of points (pressure for this example and temperature) to be used for calibration.

Based on statistical sensor measurements, a customer can decide to reduce the calibration costs by setting user-selected default values for various calibration coefficients instead of using the calibration measurements. In this case, enter the default values to be used for the selected calibration method in the coefficient entry fields at the right of the calibration screen (see Figure 4.3). These fields will not be calculated by the chosen calibration method. The calculation is disabled if there are entries for all defaults.

#### "Reset Defaults" Button

If needed, clicking the "Reset Defaults" button sets the default coefficients to 0x00 except Gain\_B/Gain\_T, which are set to unity (0x2000) and Offset\_B, which is set to a value related to the ADC offset (A2D\_Offset setting). See Table 5.1.



SSC Evaluation Kit Documentation

Preliminary

A2D Input Range [VREF]	A2D_Offset	Offset_B(hex)
-15/16 to 1/16	15/16	0x1C00
-7/8 to 1/8	7/8	0x1800
-3/4 to 1/4	3/4	0x1000
-1/2 to 1/2	1/2	0x0000
-1/4 to 3/4	1/4	0xF000
-1/8 to 7/8	1/8	0xE800
-1/16 to 15/16	1/16	0xE400

 Table 5.1 – Offset\_B Default Values Determined by A2D\_Offset Settings

#### "Bridge (%)" and "Temperature (°C)" Fields

Place the bridge/RBic<sub>iLite</sub><sup>TM</sup> pair to be calibrated in a controlled environment (for this example, a pressure and temperature chamber), and stabilize the environment at the first desired calibration point.

- $\rightarrow$  Enter the target bridge readout in % (in this case, pressure) in the "Bridge (%)" field under "Actual." (See Figure 5.1.)
- $\rightarrow$  Enter the target temperature in °C in the "Temperature (°C)" field under "Actual."
- → Click on "Add New Point." The raw data (pressure and temperature) are obtained from the part, and the point is displayed on the large graph. The point is graphed as the values entered in the previous two steps: the X-axis is the target temperature reading and the Y-axis is the target % value.
- → Change the pressure/temperature of the bridge/ RBic<sub>iLite</sub><sup>™</sup> pair being calibrated and repeat. Take as many more points as needed.

#### Hints:

For good calibration results, choose the temperature and bridge readout (%) values as close as possible to the desired working range.

#### Step 3 – Calculating and Writing the Coefficients

#### "Calculate & Write Coefficients" Button

After enough data points have been collected to calculate the calibration coefficients, click the "Calculate & Write Coefficients" button. The software calculates all the coefficients, writes them to EEPROM, and frees up that index for future use. The bridge/IC pair is now calibrated. Before the software starts to calculate and write the coefficients, all raw readings are stored in a text file (C:\Program Files\ZMD America\RBICiLite Tester\caldata.txt).

Page 19 of 39



### **RBic**<sub>iLite</sub><sup>™</sup> Low-Cost Sensor Signal Conditioner with I<sup>2</sup>C and SPI Output

SSC Evaluation Kit Documentation

Preliminary

#### 5.2 Dry Run Calibration

Steps for a Dry Run Calibration using the Artificial Bridge on the Evaluation Board:

The following steps demonstrate a simple 2-point linear calibration using the artificial bridge on the Evaluation Board.

Important: The jumpers must be connected on K6 (VBP) and K7 (VNP).

- Connect the SSC Communication (SSC CB) and the SSC ZMD31014 Evaluation Board. Insert the RBic<sub>iLite</sub><sup>TM</sup> in the SOP-8 socket on the SSC Evaluation Board. The correct orientation for pin 1 is shown in Figure 3.1.
- 2.) Connect a USB cable from the USB connector on the SSC CB to an available USB port on the PC. Verify that the green PWR LED is lit on the SSC CB.
- 3.) Start the  $\mathsf{RBIC}_{iLite}^{\mathsf{TM}}$  Tester software.
- 4.) Click "Find Port" to find the proper COM port.
- 5.) Click on "START CM." If the setup is correct, the buttons in the lower part of the main window will be activated.
- 6.) Click on "Calibration." The calibration window appears (Figure 4.3).
- 7.) In the upper right section of the calibration window, under the "Common Calibration Types" drop-down menu, choose "2-Pt Gain\_B, Offset\_B" calibration. The graph indicates the recommended pattern of two bridge readings at the same temperature.
- 8.) Click on the "Initialize" button, and click "OK" to keep the default settings for the dialog box (Figure 5.2). A unique identifier is assigned to this RBic<sub>iLite</sub><sup>TM</sup> and is written to its EEPROM

Dialog							
Sleep_Mode     Cancel     OK       Clk_Freq:     4 MHz     Comm_Type:     12C     V       Update_Rate:     25ms/6.3f     SOT_Curve:     Parabolic     V							
Fro	ont End Configu Bridge	ration Temp					
PreAmp_Mux:	Bridge 🗸	Internal 🔽					
A2D_Offset:	[-1/2,1/2] 🐱	[-1/2,1/2] 🔽					
PreAmp_Gain:	24 🗸	5 🖌					
Negative:							
LongInt: BSink:	<ul> <li>Image: Construction</li> </ul>						

Figure 5.2 – Initialization Dialog Window with Default Values (Calibration with Artificial Bridge)

Preliminary ZMD31014 SSC Evaluation Kit, Rev. 0.2, April 18, 2008



### RBic<sub>iLite<sup>™</sup></sub> Low-Cost Sensor Signal Conditioner with I<sup>2</sup>C and SPI Output

#### SSC Evaluation Kit Documentation

- 9.) The next step is to start data collection. Normally this would be done with a real bridge attached to the RBic<sub>iLite</sub><sup>TM</sup> on a remote board in a controlled chamber. Instead, this dry run calibration uses the artificial bridge inputs controlled by the on-board DAC. The DAC is controlled by the "Artificial Stimulus" slider bar or its adjacent entry field at the top of the calibration window (see Figure 4.3).
  - a. Set the DAC control to 0x300 (hex).
  - b. Enter 10 in the "Bridge (%)" field under "Actual."
  - c. Click on "Add New Point." The software obtains a raw reading from the part and graphs the new data point.
  - d. Change the DAC setting to 0xD00.
  - e. Enter 90 in the "Bridge (%)" field under "Actual."
  - f. Click on "Add New Point" again. The software obtains a new raw reading from the part and graphs the new data point.
- 10.) Because this is a 2-point calibration, the software has all the necessary data for calculating and writing the coefficients. Click on "Calculate & Write Coefficients," which should now be active.
- 11.)Close the calibration window. The temperature reading is not valid because not enough data points were collected for temperature calibration.
- 12.) Start the Normal Operation Mode (NOM) by clicking on "START NOM" and read the measurement results continuously (click Run Continuous). The DAC is now controlled by the "Artificial" slider below the data read-outs and its adjacent entry field. Adjust the DAC, and check that the displayed values make sense. For example, 0x800 should read 50% and 0xA80 should read 70%.

#### Steps for a Dry Run Calibration using the Sensor Replacement Board:

The following steps demonstrate a simple 2-point linear calibration using the artificial bridge on the Sensor Replacement Board (SRB).

Important: The jumpers must be removed from connectors K6 (VBP) and K7 (VNP).

- Connect the SSC Communication (SSC CB), the SSC ZMD31014 Evaluation Board and SSC SRB. Insert the RBic<sub>iLite</sub><sup>™</sup> in the SOP-8 socket on the SSC Evaluation Board. The correct orientation for pin 1 is shown in Figure 3.1.
- 2.) Connect a USB cable from the USB connector on the SSC CB to an available USB port on the PC. Verify that the green PWR LED is lit on the SSC CB.
- 3.) Start the  $RBIC_{iLite}$ <sup>TM</sup> Tester software.
- 4.) Click "Find Port" to find the proper COM port.
- 5.) Click on "START CM." If the setup is correct, the buttons in the lower part of the main window will be activated.
- 6.) Click on "Calibration." The calibration window appears (Figure 4.3).
- 7.) In the upper right section of the calibration window, under the "Common Calibration Types" drop-down menu, choose "2-Pt Gain\_B, Offset\_B" calibration. The graph indicates the recommended pattern of two bridge readings at the same temperature.



### RBic<sub>iLite</sub><sup>™</sup> Low-Cost Sensor Signal Conditioner with I<sup>2</sup>C and SPI Output

#### SSC Evaluation Kit Documentation

Preliminary

8.) Click on the "Initialize" button, and change the default settings to the settings shown Figure 5-3 and click "OK". A unique identifier is assigned to this RBic<sub>iLite</sub><sup>TM</sup> and is written to its EEPROM.

Dialog			
Sleep_Mode Clk_Freq: 4 MHz Update_Rate: 25ms/6 Fre PreAmp_Mux: A2D_Offset:	Ca Comm 38 SOT_ ont End Configur Bridge Bridge [-1/16,15/	ncel OK _Type: I2C Curve: Parabolic ration Temp Internal • [-1/2,1/2] •	
PreAmp_Gain:	15 🗸	5 🗸	
Negative: LongInt: BSink:			

Figure 5-3– Initialization Dialog Window with changed Values (Calibration with SRB)

- 9.) The next step is to start data collection. Normally this would be done with a real bridge attached to the RBic<sub>iLite</sub><sup>TM</sup> on a remote board in a controlled chamber. Instead, this dry run calibration uses the Sensor Replacement Board (SRB) as bridge inputs.
  - a. Turn the red potentiometer on the SRB all the way to the left.
  - b. Enter 10% in the "Bridge (%)" field under "Actual."
  - c. Click on "Add New Point." The software obtains a raw reading from the part and graphs the new data point.
  - d. Turn the red potentiometer on the SRB all the way to the right.
  - e. Enter 90% in the "Bridge (%)" field under "Actual."
  - f. Click on "Add New Point" again. The software obtains a new raw reading from the part and graphs the new data point.
- 10.)Because this is a 2-point calibration, the software has all the necessary data for calculating and writing the coefficients. Click on "Calculate & Write Coefficients," which should now be active.
- 11.)Close the calibration window. The temperature reading is not valid because not enough data points were collected for temperature calibration.
- 12.) Start the Normal Operation Mode (NOM) by clicking on "START NOM" and read the measurement results continuously (click Run Continuous) to verify the output change according to the potentiometer position.



SSC Evaluation Kit Documentation

Preliminary

#### 6 ZMD31014 Software with the ZMD SSC Terminal

#### 6.1 Protocol

The microcontroller (type ATmega32) on the SSC Communication Board (SSC CB) enables communication with the SSC Evaluation Board/ RBic<sub>iLite</sub><sup>TM</sup> using the evaluation software running on the PC. The standard I<sup>2</sup>C protocol is implemented in the microcontroller's software. The USB\_UART IC on the SSC CB transfers the signals from the microcontroller to the USB port of the PC.

For more details see the ZMD31xxxCommBoard\_DS\_Rev\_\*.pdf.

#### 6.2 ZMD SSC Terminal

The ZMD SSC Terminal is the lowest level of communication for transferring commands from the PC to the microcontroller on the SSC CB. A fully summary and detailed command description of the applicable controller commands are given in *ZMD31xxxKIT\_CommandSyntax\_Rev\_\*.xls*.

Install the SSC Terminal V201.exe from the SSC CD-ROM, which will create a ZMD SSC Terminal icon on the PC desktop. Click on this icon to active the terminal program. For the ZMD31014 communication mode, use the setting explained for  $I^2C$  (bi-directional) or SPI (only reading).

		Character Order							
	1	2	3	4,5	6,7,8	<dd></dd>			
RBic <sub>iLite</sub>	1	<b>R</b> or <b>W</b>	<b>T</b> or _						
Comments		Read or Write	Trigger Power Cycle or Not	Slave address ) (28h default)	Number of Bytes to Read and Write	Blank for Read; Data Bytes to Write			
Examples	1	W	Т	28	003	500000			
	Ι	R	_	28	002				

For more details see the ZMD31014 RBic iLite Tech Notes Calib DLL+Terminal Comm.pdf.

*Hint:* If "T" is sent for the 3<sup>rd</sup> position (instead of "\_"), the ZMD31014 is powered off and then on. "T" should be used only if power cycling is necessary for operation.



## RBic<sub>iLite<sup>™</sup></sub> Low-Cost Sensor Signal Conditioner with I<sup>2</sup>C and SPI Output

#### SSC Evaluation Kit Documentation

Preliminary

Figure 6.1 below shows a communication example. Write the command in the input line and press ENTER on the keyboard or click on "Send."

ZMD SSC Evaluation Board Terminal at COM 5	
ZMD SSC Evaluation Board V2.00 @ ZMD AG 2005	
found ZMD SSC Evaluation Board hardware at COM 4	
Comand: v Answer: <ack> V2.09 © ZMD AG 2004 - CB Comand: tl1001 Answer: <ack> Comand: t_020 Answer: <ack></ack></ack></ack>	v       Readout of SSC CB's firmware version.         t11001       Switch on both supplies with 10ms delay between power on and first command.         t_020:       Set timing for switch supply off to 20ms off before trigger restart SSC.         io. 1:       Set communication speed to 100kHz
Comand: io_1 Answer: <ack></ack>	t00000: Switch off all active channels, adjusted trig timing is preserved.
Comand: t00000 Answer: <ack> Comand: iwt28003a00000</ack>	iwt28003a00000 Start Command Mode with power on using defined delay between power-on and start communication
Answer: <ack> Comand: iw_2800340002b Answer: <ack></ack></ack>	iw_2800340001b Write to EEPROM adr.00 data 0x002b (IC default slave adr. 0x28).
Comand: iw_28003000000 Answer: <ack> Comand: ir_28003</ack>	iw_280030000000000 I2C Send command 00 0000 to slave adr 2 Read EEPROM adr 00.
Answer: <ack> 5A002B</ack>	ir_28003 Read 2(3) bytes (first byte is 5A as ACK) for digital register.
put Line – Enter ommand here.	

Figure 6.1 SSC Terminal Program Sample



SSC Evaluation Kit Documentation

Preliminary

### 7 Command/Data Pair Encoding

See the current version of the ZMD31014\_iLite\_Datasheet document for more details on commands.

In Command Mode, the master uses the I<sup>2</sup>C protocol to send 4-byte commands to the RBic<sub>iite</sub><sup>TM</sup>. This 32-bit I<sup>2</sup>C packet command/data stream consists of a I<sup>2</sup>C WRITE command byte, which is the 7-bit slave address followed by the write bit 0 (e.g.,  $0x50 = I^2$ C WRITE command byte for the default slave address 0x28 and write bit 0); then a command byte; and then16 data bits. See the *ZMD31014\_iLite\_Datasheet* document for a detailed illustration of the WRITE command packet. Table 7.1 gives the format and valid range for the three bytes that follow the initial I<sup>2</sup>C WRITE command byte.

Note: Only the commands listed in Table 7.1 are valid for the RBic<sub>iLite</sub><sup>™</sup> in Command Mode. Other encodings might cause unpredictable results. If data is not needed for the command, zeros must be supplied as data to complete the 32-bit packet.

Command Byte (Second Byte) 8 Command Bits (Hex)	Third and Fourth Bytes 16 Data Bits(Hex)	Description
0x00 to 0x13	0x0000	EEPROM Read of addresses 0x00 to 0x13. After this command has been sent and executed, a data fetch of three bytes must be performed. The first byte will be a response byte, which should be a 0x5A, and then the next two bytes will be the EEPROM data.
0x40 to 0x53	0xYYYY	Write to EEPROM addresses 0x00 to 0x13.
	(Y= data)	If the command is an EEPROM write, then the 16 bits of data sent will be written to the address specified in the 6 LSBs of the command byte.
0x80	0x0000	Start_NOM => Ends Command Mode and transitions to Normal Operation Mode. When a Start_NOM command is executed, a flag is checked to see if EEPROM was programmed during Command Mode. If so, the device will regenerate the checksum and update the signature EEPROM word.
0xA0	0x0000	Start_CM => Start Command Mode; used to enter the command interpreting mode. Start_CM is only valid during the power-on command window.

Table 7.1 – Encoding for the 3 Bytes after the Initial I<sup>2</sup>C WRITE Command Byte



SSC Evaluation Kit Documentation

Preliminary

### 8 EEPROM Bits

See the current version of the ZMD31014\_iLite\_Datasheet document for more details on the EEPROM bits.

Table 8.1 - EEPROM Word/Bit Assignment	s Programmed via the I <sup>2</sup> C Interface (RevB)
--	--

EEPROM Word	Bit Range	IC Default	Description	Note	
0x00	15:0		Cust_ID0	Customer ID byte 0 (combines with EEPROM Word 0x13 to form customer ID)	
	Z		ZMD_Config_1	Bits in the ZMD_Config_1 EEPROM word con- trol the following settings. <i>Important:</i> IC must be power-cycled after changes to this word.	
	2:0		Reserved	Leave at factory settings	
	3		ClkSpeed	Digital Core Clock Frequency 0 = 4MHz 1 = 1MHz	
	4		Comm_Type	Serial Communication Type 0 = I <sup>2</sup> C 1 = SPI	
	5		Sleep_Mode	Normal Operation Mode 0 = Update Mode 1 = Sleep Mode	
0x01	7:6		Update_Rate	1 MHz Clock $4 MHz Clock$ $00 = 1.4 ms$ $00 = 0.4 ms$ $01 = 4.9 ms$ $01 = 1.28 ms$ $10 = 25.1 ms$ $10 = 6.33 ms$ $11 = 124.4 ms$ $11 = 31.16 ms$	
	8		Reserved	Leave at factory setting	
	9		SOT_curve	Type of second-order curve correction on bridge. If set to 0, the bridge SOT will correct for a parabolic curve. If set to 1, the bridge SOT will correct for an S-shaped curve.	
	11:10		TC_Sign	TC_Sign[0] = 1, Tco is a negative number. TC_Sign[1] = 1, Tcg is a negative number.	
	15:12		SOT_Sign	SOT_Sign[0] =1, SOT_bridge is negative. SOT_Sign[1] =1, SOT_tco is negative. SOT_Sign[2] =1, SOT_tcg is negative. SOT_Sign[3] =1, SOT_T is negative.	
0x02			ZMD_Config_2	Bits in the ZMD_Config_2 EEPROM word con- trol the following settings. <i>Important:</i> IC must be power-cycled after changes to this word.	



## $RBic_{iLite}$ <sup>TM</sup> Low-Cost Sensor Signal Conditioner with I<sup>2</sup>C and SPI Output

SSC Evaluation Kit Documentation

Preliminary

EEPROM Word	Bit Range	IC Default	Description	Note
	0		SPI_Polarity	Configure clock polarity of SPI interface 0 = MISO changes on SCLK negative edge. 1 = MISO changes on SCLK positive edge.
	2:1		Diag_cfg	2-bit diagnostic configuration field. Diag_cfg[0] enables sensor connection check. Diag_cfg[1] enables sensor short checking.
	9:3	0101000	Slave_Addr	I <sup>2</sup> C slave address (default = 0x28). Valid range is 0x00 to 0x7F.
	12:10	011	Comm_lock	Communications address lock 011 => locked All other => unlocked When communication is locked, I <sup>2</sup> C communi- cation will only respond to its programmed address. Otherwise if communication is unlocked, I <sup>2</sup> C will respond to any address.
	15:13		EEP_Lock	EEPROM lock 011 = locked All other = unlocked When EEPROM is locked, the internal charge pump is disabled and the EEPROM can never be programmed again. <b>NOTE:</b> Next command must be Start_NOM so that the signature is calculated and written to EEPROM before power down. <sup>1</sup>
0x03	15:0		Offset_B	Signed 16-bit offset for bridge correction.
0:04	14:0		Gain_B	15-bit magnitude of bridge gain. Always positive. Unity is 0x2000.
UXU4	15		Gain8x_B	Multiple Gain_B by 8 0 = Gain_B x 1 1 = Gain_B x 8
0x05	15:0		Тсд	Coefficient for temperature correction of bridge gain term. Tcg = 16-bit magnitude of Tcg term with sign determined by TC_Sign[1].

<sup>&</sup>lt;sup>1</sup> If the part is power cycled instead, the lock will take effect, and the checksum will be permanently wrong. In this case, the part will always output a diagnostic state.



## $RBic_{iLite}$ <sup>TM</sup> Low-Cost Sensor Signal Conditioner with I<sup>2</sup>C and SPI Output

SSC Evaluation Kit Documentation

Preliminary

EEPROM Word	Bit Range	IC Default	Description	Note	
0x06	15:0		Тсо	Coefficient for temperature correction of bridge offset term. Tco = 16-bit magnitude of Tco term with sign determined by TC_Sign[0].	
0x07	15:0		SOT_tco	2 <sup>nd</sup> order term applied to Tco. This term is a 16- bit magnitude with sign determined by SOT_Sign[1].	
0x08	15:0		SOT_tcg	2 <sup>nd</sup> order term applied to Tcg. This term is a 16- bit magnitude with sign determined by SOT_Sign[2].	
0×09	15:0		SOT_bridge	2 <sup>nd</sup> order term applied to the bridge measure- ment. This term is a 16-bit magnitude with sign determined by SOT_Sign[0]. SOT_curve selects parabolic or S-shaped fit.	
0x0A	15:0		Offset_T	Temperature offset correction coefficient.	
	14:0		Gain_T	Temperature gain correction coefficient.	
0x0B	15		Gain8x_T	Multiple Gain_T by 8 0 = Gain_T x 1 1 = Gain_T x 8	
0x0C	15:0		SOT_T	2 <sup>nd</sup> order term applied to the temperature reading. This term is a 16-bit magnitude with sign determined by SOT_Sign[3]. Always a parabolic fit.	
0x0D	15:0		T <sub>SETL</sub>	Stores raw temperature reading at the tempera- ture at which low calibration points were taken.	
0x0E	15:0		Unused	Leave at factory settings	
0x0F			B_Config Register	Front-end configuration word for measurement of BP/BN (Bridge).	
	3:0		A2D_Offset [3:0]	A2D_Offset [3:0]         A2D_Offset Point Shift           1111         [-15/16,1/16]           1110         [-7/8,1/8]           1100         [-3/4,1/4]           1000         [-1/2,1/2]           0100         [-1/4,3/4]           0010         [-1/8,7/8]           0001         [-1/16,15/16]	

Preliminary ZMD31014 SSC Evaluation Kit, Rev. 0.2, April 18, 2008

Page 28 of 39



## $RBic_{iLite}$ <sup>TM</sup> Low-Cost Sensor Signal Conditioner with I<sup>2</sup>C and SPI Output

SSC Evaluation Kit Documentation

Preliminary

EEPROM Word	Bit Range	IC Default	Description	Note
	6:4		PreAmp_Gain [2:0]	PreAmp_Gain [2:0]         GAIN           000         1.5           100         3           001         6           101         12           010         24           110         48           011         96           111         192
	7		Gain_Polarity	Gain polarity: 0=negative gain, 1=positive gain
	8		LongInt	If 1, selects long integration period (11-coarse + 3 fine), which results in lower noise, slower conversion; otherwise, the conversion is done as (9 coarse + 5 fine).
	9		Bsink	If 1, Bsink pull-down will be enabled during the measurement.
	11:10		PreAmp_Mux [1:0]	PreAmp_Mux [1:0] Measurement 10 Bridge 11 Single-ended input
	12		Disable_Nulling	Disable Nulling 0 = Nulling On 1 = Nulling Off (Use this setting if PreAmp gain ≤6.)
	15:13		Reserved	Leave at factory settings



## $RBic_{iLite}$ <sup>TM</sup> Low-Cost Sensor Signal Conditioner with I<sup>2</sup>C and SPI Output

SSC Evaluation Kit Documentation

Preliminary

EEPROM Word	Bit Range	IC Default	Description	Note		
			T_Config Register	Front-end configuration word for temperature measurement		
	3:0		A2D_Offset [3:0]	A2D_Offset [3:0]         A2D_Offset Point Shift           1111         [-15/16,1/16]           1110         [-7/8,1/8]           1100         [-3/4,1/4]           1000         [-1/2,1/2]           0100         [-1/4,3/4]           0010         [-1/8,7/8]           0001         [-1/16,15/16]		
0x10	6:4		PreAmp_ Gain[2:0]	PreAmp_Gain [2:0]       GAIN         000       1.5         100       3         001       6         101       12         010       24         110       48         011       96         111       192		
	7		Gain_Polarity	Gain polarity; 0 = negative, 1= positive gain.		
	8		LongInt	If 1, selects long integration period (11-coarse + 3 fine), for lower noise, slower conversion; otherwise, the conversion is (9 coarse + 5 fine).		
	9		Bsink	If 1, Bsink pull-down will be enabled during the measurement.		
	11:10		PreAmp_Mux [1:0]	PreAmp_Mux [1:0] Measurement 00 Ext. Temperature 01 Internal Temperature		
	12		Disable_Nulling	Disable Nulling 0 = Nulling On 1 = Nulling Off (Use this setting if PreAmp gain ≤6.)		
	15:13		Reserved	Leave at factory settings		
	15:0		Reserved	Leave at factory settings		
0x12	15:0		Signature	Generated through a linear feedback shift register (LFSR). Signature checked on power- up to ensure EEPROM contents integrity.		
0x13	15:0		Cust_ID1	Customer ID byte 1 (combines with Word 0x00 to form customer ID).		

Preliminary ZMD31014 SSC Evaluation Kit, Rev. 0.2, April 18, 2008

Page 30 of 39



### **RBic**<sub>iLite</sub><sup>™</sup> Low-Cost Sensor Signal Conditioner with I<sup>2</sup>C and SPI Output

SSC Evaluation Kit Documentation

Preliminary

#### 9 Related Documents

- ZMD31xxxKIT\_CommBoard\_DS.pdf
- ZMD31xxxKIT\_SensorReplacementBoard\_DS.pdf
- ZMD31xxxCommandSyntax.xls
- ZMD31014 RBic<sub>iLite</sub><sup>TM</sup> Datasheet
- ZMD31014 RBic<sub>iLite</sub><sup>TM</sup> SSC Kits Feature Sheet (includes ordering codes and price information)
- ZMD31014 RBic<sub>iLite</sub><sup>TM</sup> Die Dimensions and Pad Coordinates

For the current revisions of this document and of the related documents, please go to <u>www.zmd.biz</u> or contact the ZMD sales team (see addresses on last page).



RBic<sub>iLite</sub><sup>™</sup> Low-Cost Sensor Signal Conditioner with I<sup>2</sup>C and SPI Output

SSC Evaluation Kit Documentation

Preliminary





Preliminary ZMD31014 SSC Evaluation Kit, Rev. 0.2, April 18, 2008

Page 32 of 39



RBic<sub>iLite</sub><sup>™</sup> Low-Cost Sensor Signal Conditioner with I<sup>2</sup>C and SPI Output *SSC Evaluation Kit Documentation* 

Preliminary

#### Appendix B: List of Error Messages in the Software

(TBD)

Preliminary ZMD31014 SSC Evaluation Kit, Rev. 0.2, April 18, 2008

Page 33 of 39



### **RBic**<sub>iLite</sub><sup>™</sup> Low-Cost Sensor Signal Conditioner with I<sup>2</sup>C and SPI Output

SSC Evaluation Kit Documentation

Preliminary

#### Appendix C: Format of the caldata.txt file

04/14/08 14:02:17 1208199737 3 2 3048 1176 0 72

35.7147 10 10.1563 25

64.3791 90 10.1563 25

Date	Time	Machine_TIME	ID	NUM_POINTS	B_CFG	T_CFG	OFFSET_B	CFG1
04/14/08	14:02:17	1208199737	3	2	3048	1176	0	128

RAW_B	BR	RAW_T	TEMP
35.7147	10	10.1563	25
64.3791	90	10.1563	25

The top line contains calibration specific information (1 part):

Date, time, and machine time of calibration

ID:Calibration ID number --this is what is programmed into the part for retrieval

SOT\_TYPE: 0  $\rightarrow$  Parabolic, 1  $\rightarrow$  S-Shape

NUM\_POINTS: Number of points currently in the calibration

B\_CFG: Bridge configuration register EEPROM word 0x0F

T\_CFG: Temperature configuration register EEPROM word 0x10

OFFSET\_B ADC Shift related OFFSET\_B (see Table 5.1)

CFG1: Configuration word Config1 (EEPROM word 0x01)

The next lines contain calibration point specific data:

RAW\_B: Raw Bridge Readings

BR: Desired Bridge ("Actual")

RAW\_T: Raw temperature reading

TEMP: Desired Temperature ("Actual")



## ZMD31014 RBic<sub>iLite</sub><sup>™</sup> Low-Cost Sensor Signal Conditioner with I<sup>2</sup>C and SPI Output SSC Evaluation Kit Documentation

Preliminary

#### Appendix D: Driver Installation on Windows 2000 Operating Systems

Follow these steps to install the basic USB driver on Windows 2000 operating systems:

1. Connect the SSC Evaluation Board to a USB port with a USB cable. The "Found New Hardware" wizard automatically launches, and the following dialog box appears:

Found New Hardware Wizard		
	Welcome to the Found New Hardware Wizard This wizard helps you instal a device driver for a hardware device.	
ok.	<back next=""> C</back>	Cancel
	Found I	J New Hardware USB <> Serial J alling

2. Click Next. The following dialog box appears. Select "Search for a suitable driver for my device (recommended)".

ound New Hardware Wizard	
Install Hardware Device Drivers A device driver is a software program that enables a hardware device to wo an operating system.	rk with
This wizard will complete the installation for this device:	
A device driver is a software program that makes a hardware device work. V	Windows
installation click Next. What do you want the wizard to do?	-
<ul> <li>Search for a suitable driver for my device (recommended)</li> <li>Display a list of the known drivers for this device so that I can choose driver</li> </ul>	a specific
< Back Next>	
	Found New Hardware
	Nistalling

Preliminary ZMD31014 SSC Evaluation Kit, Rev. 0.2, April 18, 2008

Page 35 of 39



### $RBic_{iLite}{}^{{}^{\rm T\!M}}$ Low-Cost Sensor Signal Conditioner with $I^2C$ and SPI Output

#### SSC Evaluation Kit Documentation

Preliminary

3. Click on Next. The following dialog appears. Select "CD-ROM drives."



4. Click on Next. The following display appears confirming that the driver was found on the CD-ROM drive.



Page 36 of 39



#### SSC Evaluation Kit Documentation

Preliminary

5. Click on Next. The following display confirms the installation of the basic USB driver.

Found New Hardware Wizard		
	Completing the Found New Hardware Wizard WSB High Speed Serial Converter Windows has finished installing the software for this device. To close this wizard, click Finish.	
sk	Kenter Ke	
• • •	Found New Hardw SS USB ↔ Installing	are Serial

6. Click on Finish. The second USB driver installation automatically starts. This second required USB driver causes the USB device to appear to the system as a virtual COM port. Follow the same steps as outlined under *Installing the Basic USB Driver* above to complete this second driver installation.



### **RBic**<sub>iLite</sub><sup>™</sup> Low-Cost Sensor Signal Conditioner with I<sup>2</sup>C and SPI Output

#### SSC Evaluation Kit Documentation

Preliminary

7. Verify that the new hardware is operating properly before continuing. Access the control panel by clicking Start → Settings → Control Panel. Double click the "System" icon. The following dialog box appears.

System Re	store	Automat	tic Updates	Remote
General	Computer N	ame	Hardware	Advanced
2 2			Add Hardwar	re Wizard
Device Mana	iger		Add Hardwar	re Wizard
Device Mana Th on pro	ager e Device Manage your computer. L iperties of any de	er lists all t Ise the De vice.	Add Hardwar he hardware device evice Manager to cl	re Wizard es installed hange the

8. Click on the "Hardware" tab, and then on "Device Manager." The following display appears.



If the USB is operating properly, "ZMD SSC Evaluation Kit (COMx)" appears under "Ports (COM & LPT)." Typically, the "x" is 3 or 4. Remember this virtual COM port number. It is the COM port to select when using the software provided with the SSC Evaluation Kit.

Preliminary ZMD31014 SSC Evaluation Kit, Rev. 0.2, April 18, 2008



**ZMD31014** RBic<sub>iLite</sub><sup>TM</sup> Low-Cost Sensor Signal Conditioner with I<sup>2</sup>C and SPI Output *SSC Evaluation Kit Documentation* 

Preliminary

#### **Restrictions:**

The ZMD AG RBic<sub>Lite</sub><sup>™</sup> SSC Evaluation Kit hardware and software are designed for RBic<sub>Lite</sub><sup>™</sup> evaluation, laboratory setup and the SSC Evaluation module only.

The ZMD AG RBic<sub>Lite</sub> <sup>TM</sup> SSC Evaluation Kit hardware and software must not be used for module production and production test setups. ZMD AG shall not be liable for any damages arising out of defects resulting from (i) delivered hard and software (ii) non-observance of instructions contained in this manual, or (iii) misuse, abuse, use under abnormal conditions or alteration by anyone other than ZMD AG. To the extent permitted by law, ZMD AG hereby expressly disclaims and User expressly waives any and all warranties, whether express, implied or statutory, including, without limitation, implied warranties of merchantability and of fitness for a particular purpose, statutory warranty of non-infringement and any other warranty that may arise by reason of usage of trade, custom or course of dealing.

This information applies to a product under development. Its characteristics and specifications are subject to change without notice. ZMD assumes no obligation regarding future manufacture unless otherwise agreed to in writing. The information furnished hereby is believed to be correct and accurate. However, ZMD shall not be liable to any customer, licensee or any other third party for any damages in connection with or arising out of the furnishing, performance or use of this technical data. No obligation or liability to any customer, licensee or any other third party shall result from ZMD's rendering of technical or other services.

For further information:

**ZMD AG** Grenzstrasse 28 01109 Dresden, Germany Phone +49 (0)351-8822-366 Fax +49 (0)351-8822-337 <u>sales@zmd.de</u> www.zmd.biz **ZMD America, Inc**. 201 Old Country Road, Suite 204 Melville, NY 11747, USA Phone +01 (631) 549-2666 Fax +01 (631) 549-2882

<u>sales@zmda.com</u> <u>www.zmd.biz</u>

#### ZMD Far East

1F, No.14, Lane 268 Sec. 1 Guangfu Road HsinChu City 300 Taiwan Phone +886.3.563.1388 Fax +886.3.563.6385 sales@zmd.de www.zmd.biz

Preliminary ZMD31014 SSC Evaluation Kit, Rev. 0.2, April 18, 2008

Page 39 of 39

© ZMD AG, 2008