

# **HA16117F Series**

## **CMOS Watchdog Timer**

REJ03F0142-0300

(Previous: ADE-204-018B)

Rev.3.00 Jun 15, 2005

### **Description**

The HA16117F Series of ICs make a micro-processor (MPU) system fail-safe by monitoring its power supply to detect voltage drops, and monitoring a P-RUN (program running) pulse to detect system crashes. Also referred to as watchdog timers, these devices are essential in systems that aim for high levels of crash protection. Fabricated by a CMOS process, they consume little power and are ideally suited for battery-operated systems.

These ICs are available in versions for industrial and communications equipment and automotive applications, as well as for consumer products.

#### **Functions**

- ower-on reset
  - Sends a RES signal to the MPU for a fixed time at power-on
- Watchdog timer (WDT)
  - Monitors a P-RUN signal from the MPU and sends the MPU a RES signal if P-RUN departs from a set frequency range
- Auto-reset
  - Outputs RES signals to the MPU at clocked intervals while P-RUN remains abnormal
- Supply voltage supervision

Outputs a low RES signal if the supply voltage (same as the MPU's  $V_{CC}$ ) falls below a low threshold level ( $V_{TL}$ ). The threshold differs for different ICs in the series, allowing designers to choose an IC matching system requirements (see ordering information)

#### **Features**

- Low power consumption : Operating (ACC pin low) = 0.5 mW (Typ)
  - : Standby (ACC pin high) = 0.2 mW (Typ)
- Watchdog timer on/off control by ACC input signal
- Independent auto-reset high and low times (t<sub>RH</sub> and t<sub>RL</sub>)
- Watchdog monitoring by frequency filtering (independent of duty cycle)
- High-precision low voltage detection (±2%)
- Space- and weight-saving 8-pin SOP package


### **Ordering Information**

The HA16117F Series includes three ICs with different low threshold levels (V<sub>TL</sub>).

Type No.	Low Threshold Voltage (V <sub>TL</sub> )
HA16117FPA/FPAJ	4.4 V Typ
HA16117FPB/FPBJ	4.2 V Typ
HA16117FPC/FPCJ	4.0 V Typ



#### **Pin Arrangement**




### **Pin Description**

Pin No.	Symbol	Function
1	Vcc	Power supply voltage input
2	P-RUN	Watchdog timer (WDT) input
3	C <sub>F</sub>	Connected capacitor C <sub>F</sub> determines WDT filter characteristic (normal frequency range)
4	C <sub>R</sub>	Connected capacitor $C_R$ determines $t_{\text{ON}}$ for power-on reset and $t_{\text{OFF}}$ , $t_{\text{RH}}$ , and $t_{\text{RL}}$ for auto-reset
5	RES	Reset signal output from WDT and voltage supervision circuits
6	GND	Ground
7	ACC	WDT on/off control input (on when ACC is low)
8	Tadj *	For adjusting t <sub>RH</sub> and t <sub>OFF</sub> (divide V <sub>CC</sub> to get the adjustment voltage)

Note: The low-voltage threshold cannot be modified by changing the external resistors connected to the Tadj pin.



#### **Block Diagram**



The HA16117F consists of a low voltage detector, power-on and auto-reset circuit, and watchdog timer.

#### Low Voltage Detector

Uses a reference voltage source (≈ 1.25 V) and high-precision comparator to detect drops in the supply voltage.

#### Power-On and Auto-Reset Circuit

Generates the  $\overline{RES}$  waveform, using a multivibrator consisting of a current source  $I_1$  that charges the external capacitor  $C_R$ , a current source  $I_2$  that discharges  $C_R$ , and a comparator.

#### **Watchdog Timer**

Reshapes the P-RUN signal (programming-running pulse) from the MPU to obtain a 50% duty cycle, then converts frequency to duty cycle in the watchdog filter (WD filter).

The watchdog filter is a bandpass filter. The duty cycle of the filter output is highest in the normal frequency range of P-RUN.


The watchdog filter output controls  $I_2$  in the multivibrator, the higher the duty cycle of the watchdog filter output, the shorter the time during which  $I_2$  discharges  $C_R$ . If the duty cycle is high enough then  $C_R$  is held at a high potential, preventing the multivibrator from firing, and the  $\overline{RES}$  output remains high.

## **Absolute Maximum Ratings**

 $(Ta = 25^{\circ}C)$ 

		R		
Item	Symbol	HA16117FPA/FPB/FPC	HA16117FPAJ/FPBJ/FPCJ	Unit
Power supply voltage	Vcc	-0.3 to +14	−0.3 to +14	V
P-RUN input voltage	$V_P$	V <sub>CC</sub>	Vcc	V
ACC input voltage	V <sub>ACC</sub>	14	14	V
RES output current	I <sub>RES</sub>	10	10	mA
Permissible dissipation *1	P <sub>T</sub>	300	300	mW
Operating temperature range	Topr	−30 to +85	-40 to +85	°C
Storage temperature	Tstg	−55 to +125	-55 to +125	°C

Note: 1. This is the value when mounted on a glass epoxy substrate with 30% wiring density, up to an ambient temperature of 83°C. Above that temperature, derate by 7.14 mW/°C.




### **Electrical Characteristics**

 $(V_{CC} = 5 \text{ V}, \text{ Ta} = 25^{\circ}\text{C}, C_F = 0.01 \text{ } \mu\text{F}, C_R = 0.1 \text{ } \mu\text{F}, R_1 = 510 \text{ } k\Omega, R_2 = 750 \text{ } k\Omega)$ 

Item		Symbol	Min	Тур	Max	Unit	Test Conditions	
General	eneral Operating supply current		I <sub>CC1</sub>	-	100	-	μΑ	$V_{ACC} = 0 \text{ V},$ $f_{P-RUN} = 100 \text{ Hz}$
			I <sub>CC2</sub>	-	200	600	μΑ	$V_{ACC} = 0 \text{ V},$ $f_{P-RUN} = 20 \text{ kHz}$
	Standby supply	current	I <sub>STBY</sub>	-	43	100	μΑ	V <sub>ACC</sub> = 12 V
Low	Low voltage	HA16117FPA/FPAJ	$V_{TL}$	4.3	4.4	4.5	V	When V <sub>CC</sub> drops
voltage	threshold	HA16117FPB/FPBJ		4.1	4.2	4.3	V	
detector	level	HA16117FPC/FPCJ		3.9	4.0	4.1	V	<u> </u>
	Hysteresis widt	h	V <sub>HYS</sub>	50	100	150	mV	
ACC	Low input volta	ge	V <sub>IL1</sub>	-	-	0.8	V	
	High input voltage		V <sub>IH1</sub>	2.0	_	_	V	
P-RUN	Low input volta	ge	V <sub>IL2</sub>	_	_	0.8	V	
input	High input volta	ige	V <sub>IH2</sub>	2.0	_	-	V	
WDT	Power-on reset time		ton	24	40	56	ms	
	Reset-clock off time		toff *1	78	130	182	ms	
	Reset low time		t <sub>RL</sub>	12	20	28	ms	
	Reset high time		t <sub>RH</sub>	36	60	84	ms	P-RUN pin = 0 V
Low setup time			t <sub>SL</sub>	1	-		ms	
	High setup time		t <sub>SH</sub>	-		1	ms	
RES	RES low voltag	е	VoL	-	70	0.4	V	I <sub>OL</sub> = 1 mA
output	RES high volta	RES high voltage		_	Vcc	_	V	Open
	Reset function starting voltage		V <sub>RES</sub>		0.8	1.4	V	
Constant range	3		К	0.55	0.6	0.8	-	$K = R_2 / (R_1 + R_2)$
Operating supply voltage range		V <sub>CCRNG</sub>	V <sub>TL</sub>	_	6.0	V		

Note: 1. Reset-clock off time t<sub>OFF</sub> is provided a shown in the under figure.



### **Timing Waveforms and Functional Description**




Figure 1 Timing Waveforms

#### **Watchdog On/Off Function**

A feature of the HA16117F is that watchdog supervision can be switched on and off. When the watchdog function is switched on, both the supply voltage and

P-RUN input are monitored to detect abnormal conditions. When the watchdog function is switched off (standby mode), only the supply voltage is monitored. Watchdog supervision is switched on and off by the input at the ACC pin (pin 7): Supervision is on when ACC is low, and off when ACC is high.

Many MPUs have a standby mode in which the CPU stops running but memory contents are retained. In standby mode, program execution halts and I/O ports go to the high-impedance state, so there is no need for the watchdog timer to supervise pulse output from an I/O port to detect abnormal conditions. Power can be saved by placing both the MPU and HA16117F in standby mode at the same time. The HA16117F is designed to draw a typical standby current I<sub>STBY</sub> of only 43 µA Typ when the watchdog function is switched off.

#### ACC Pin (pin 7) and RES Output

When the MPU returns from standby mode to normal operation it generally takes 10 to 200 ms for the clock oscillator in the MPU to stabilize. The  $\overline{RES}$  signal is not output during this setup time. After the setup time ( $t_{SL}$ ) has elapsed,  $\overline{RES}$  is output if the P-RUN signal from the MPU is still abnormal.




Figure 2 ACC Pin and RES Output

#### **Internal Operation and Usage Notes**

Figure 3 shows an equivalent circuit of the watchdog timer block with a  $V_{CC}$  pin level of 5 V and ACC pin level of 0 V, and the following pages show internal operation timing charts for different P-RUN frequencies. (Descriptions apply to conditions  $C_F = 0.01 \, \mu F$ ,  $C_R = 0.1 \, \mu F$ ,  $R_2/(R_1 + R_2) = 0.6$ .)

#### Operation

The power-on and auto-reset circuit is a multivibrator with timing controlled by  $C_R$  charge current  $I_1$  and discharge current  $I_2$ . As  $I_1:I_2\approx 3:1$  (Typ design value), when the (WD) (watchdog filter circuit output) on-duty is 25% or above, the  $C_R$  pin potential does not fall below 1.6 V. Therefore, (C) in the figure below is fixed low, and  $\overline{RES}$  is not output. The (WD) on-duty varies according to the P-RUN frequency. If the frequency is lower or higher than the design value, the (WD) on-duty decreases, and at 25% or below,  $\overline{RES}$  is output. Refer to the timing charts on the following pages for an explanation of the operation of the watchdog filter.

#### **Usage Notes**

- When the P-RUN frequency reaches 20 kHz or above, t<sub>OFF</sub> is short (see the timing charts on the following pages).
   This must be borne in mind in the design stage.
- If the P-RUN frequency fluctuates, RES may also be output within the normal detection set frequency (see the timing charts on the following pages).
- Detection frequencies f<sub>H</sub> and f<sub>L</sub> described in the Data Book are Typ values, and a certain amount of dispersion can be expected. A margin of ±30% or more should be allowed for in the design.






Figure 3 Watchdog Timer Evaliation Circuit


### 1. When P-RUN signal is not input




#### 2. With a low-frequency P-RUN signal ( $\approx$ 13 Hz to 26 Hz)




### 3. With a 10 kHz P-RUN signal




### 4. With a 150 kHz P-RUN signal




#### 5. $t_{OFF}$ when P-RUN signal $\approx 90 \text{ kHz}$



#### 6. When P-RUN frequency fluctuates (1)




### 7. When P-RUN frequency fluctuates (2)



#### 8. Summary of cases where P-RUN frequency fluctuates

If there is a double-pulse in P-RUN,  $\overline{\text{RES}}$  may be output if the double-pulse has multiple frequency components. If the P-RUN frequency fluctuates, refer to the following when making the P-RUN setting.






Note: 2. This is the region when  $f_{P-RUN}$  is constant.

If  $f_{P-RUN}$  fluctuates within the normal detection region, the following applies:

Normal detection is performed when the condition  $f_{P-RUN\,H}/f_{P-RUN\,L} < M$  is satisfied.



### Setting of RES Timing and Watchdog Frequency Range

Different MPUs have different  $\overline{RES}$  timing requirements. The minimum reset time ( $t_{ON}$ ) required at power-on (rise of  $V_{CC}$ ) is 20 ms for some MPUs and 100 ms for others.

 $\overline{\text{RES}}$  timing waveform parameters must be selected according to the MPU. With the HA16117F the timing of the  $\overline{\text{RES}}$  output and the watchdog frequency range can both be set by external constants (C<sub>F</sub>, C<sub>R</sub>, and K).

		Parameters			
Item	Symbol	CR (pin 4)	CF (pin 3)	K (pin 8) *1	
Power-on reset time	t <sub>ON</sub>	•			
Reset-clock off time	t <sub>OFF</sub>	•	<b>▲</b> * <sup>2</sup>	•	
Reset low time	t <sub>RL</sub>	•			
Reset high time	t <sub>RH</sub>	•		•	
Watchdog frequency high	f <sub>H</sub>		•	•	
Watchdog frequency low	f <sub>L</sub>	•	•	•	

Notes: 1.  $K = R_2 / (R_1 + R_2)$ 

- 2. Variability of  $t_{OFF}$  increases with increasing  $C_F$ . The variability  $\Delta t_{OFF}$  is approximately 3.3 (M $\Omega$ )  $\times$   $C_F$  ( $\mu F$ ), so  $C_F \le 0.01$  ( $\mu F$ ) is recommended.
- 3. External constants should be selected with reference to the formulas in tables 1 and 2.

Table 1 Calculation of RES Output Timing

Item	Formula	Notes
t <sub>ON</sub> (ms)	$400 (Ω) \times C_R (μF)$	ton and toff can be set independently
t <sub>OFF</sub> (ms)	1.99 × t <sub>RH</sub> (ms)	
t <sub>RL</sub> (ms)	$0.5 \times t_{ON}$ (ms)	t <sub>RL</sub> and t <sub>RH</sub> can be set independently
$t_{RH}$ (ms)	$\frac{1.6 \text{ (V)}}{\text{K} \times 31 \text{ ($\mu$A)} - 15.8 \text{ ($\mu$A)}} \times \text{C}_{\text{R}} \text{ ($\mu$F)} \times 10^3$	
t <sub>SL</sub> (ms)	≈ t <sub>OFF</sub> (ms)	

Table 2 Calculation of Watchdog Frequency Range

Item	Formula
f <sub>H</sub> (MHz)	$\frac{1}{500 \ (\Omega) \times \textbf{C}_{\text{F}} \ (\mu\text{F})} \times \frac{\textbf{t}_{\text{RH}} \ (\text{ms}) - \textbf{t}_{\text{RL}} \ (\text{ms})}{\textbf{t}_{\text{RH}} \ (\text{ms}) + \textbf{t}_{\text{RL}} \ (\text{ms})}$
f <sub>L</sub> (Hz)	$\frac{1}{1.7 \text{ (M}\Omega) \times C_F \text{ ($\mu$F$)}} \times \frac{t_{\text{RL}} \text{ (ms)}}{t_{\text{RH}} \text{ (ms)} + t_{\text{RL}} \text{ (ms)}}  \text{or}  \frac{1}{t_{\text{OFF}} \text{ (ms)}} \times 10^3$ Whichever is larger

#### **Selection of External Constants**

If the reset duration necessary for the MPU to operate reliably at power-on is known, there is a simple procedure for selecting external constants, starting from the power-on reset time  $(t_{ON})$ .







Figure 4 Procedure for Selecting External Constants


## **Application Example**





## **Operating Characteristics and Test Circuits**

























P-RUN Input Frequency vs. K (Tadj constant)







Test circuit

Notes: 1. Normal detection is assumed when  $\overline{RES}$  is not output.

2. The figure at left is for a constant P-RUN frequency.









Test circuit

Notes: 1. Normal detection is assumed when  $\overline{RES}$  is not output.

2. The figure at left is for a constant P-RUN frequency.

#### P-RUN Low Threshold Frequency vs. $C_F$ Capacitance







Test circuit

- Notes: 1. Normal detection is assumed when  $\overline{RES}$  is not output.
  - 2. The figure at left is for a constant P-RUN frequency.


#### P-RUN Input Frequency vs. Ambient Temperature






Test circuit

- Notes: 1. Normal detection is assumed when  $\overline{\text{RES}}$  is not output.
  - 2. The figure at left is for a constant P-RUN frequency.



### **Package Dimensions**



Renesas Technology Corp. Sales Strategic Planning Div. Nippon Bldg., 2-6-2, Ohte-machi, Chiyoda-ku, Tokyo 100-0004, Japan

Keep safety first in your circuit designs!

1. Renesas Technology Corp. puts the maximum effort into making semiconductor products better and more reliable, but there is always the possibility that trouble may occur with them. Trouble with semiconductors may lead to personal injury, fire or property damage.

Remember to give due consideration to safety when making your circuit designs, with appropriate measures such as (i) placement of substitutive, auxiliary circuits, (ii) use of nonflammable material or (iii) prevention against any malfunction or mishap.

#### Notes regarding these materials

- Notes regarding these materials

  1. These materials are intended as a reference to assist our customers in the selection of the Renesas Technology Corp. product best suited to the customer's application; they do not convey any license under any intellectual property rights, or any other rights, belonging to Renesas Technology Corp. a third party.

  2. Renesas Technology Corp. assumes no responsibility for any damage, or infringement of any third-party's rights, originating in the use of any product data, diagrams, charts, programs and algorithms represents information on products at the time of publication of these materials, and are subject to change by Renesas Technology Corp. without notice due to product improvements or other reasons. It is therefore recommended that customers contact Renesas Technology Corp. or an authorized Renesas Technology Corp. product distributor for the latest product information before purchasing a product listed herein.

  The information described here may contain technical inaccuracies or typographical errors.

  Renesas Technology Corp. assumes no responsibility for any damage, liability, or other loss rising from these inaccuracies or errors.

  Please also pay attention to information published by Renesas Technology Corp. by various means, including the Renesas Technology Corp. Semiconductor home page (http://www.renesas.com).

  4. When using any or all of the information contained in these materials, including product data, diagrams, charts, programs, and algorithms, please be sure to evaluate all information as a total system before making a final decision on the applicability of the information and products. Renesas Technology Corp. assumes no responsibility for any damage, liability or other loss resulting from the information contained herein.

  5. Renesas Technology Corp. semiconductors are not designed or manufactured for use in a device or system that is used under circumstances in which human life is potentially at stake. Please contact Renesas Technology Corp. or an authoriz
- use.

  6. The prior written approval of Renesas Technology Corp. is necessary to reprint or reproduce in whole or in part these materials.

  7. If these products or technologies are subject to the Japanese export control restrictions, they must be exported under a license from the Japanese government and cannot be imported into a country other than the approved destination.

  Any diversion or reexport contrary to the export control laws and regulations of Japan and/or the country of destination is prohibited.

  8. Please contact Renesas Technology Corp. for further details on these materials or the products contained therein.

#### RENESAS SALES OFFICES

http://www.renesas.com

Refer to "http://www.renesas.com/en/network" for the latest and detailed information.

**Renesas Technology America, Inc.** 450 Holger Way, San Jose, CA 95134-1368, U.S.A Tel: <1> (408) 382-7500, Fax: <1> (408) 382-7501

Renesas Technology Europe Limited
Dukes Meadow, Millboard Road, Bourne End, Buckinghamshire, SL8 5FH, U.K. Tel: <44> (1628) 585-100, Fax: <44> (1628) 585-900

Renesas Technology Hong Kong Ltd.
7th Floor, North Tower, World Finance Centre, Harbour City, 1 Canton Road, Tsimshatsui, Kowloon, Hong Kong Tel: <852> 2265-6688, Fax: <852> 2730-6071

**Renesas Technology Taiwan Co., Ltd.** 10th Floor, No.99, Fushing North Road, Taipei, Taiwan Tel: <886> (2) 2715-2888, Fax: <886> (2) 2713-2999

Renesas Technology (Shanghai) Co., Ltd. Unit2607 Ruijing Building, No.205 Maoming Road (S), Shanghai 200020, China Tel: <86> (21) 6472-1001, Fax: <86> (21) 6415-2952

Renesas Technology Singapore Pte. Ltd.
1 Harbour Front Avenue, #06-10, Keppel Bay Tower, Singapore 098632 Tel: <65> 6213-0200, Fax: <65> 6278-8001

1	
1	
1	
1	
-	
-	
-	
-	
1	
1	
L	_